

**HOLMAN**

# weather **WHIZ**™

**WIRELESS WEATHER READER**



DOWNLOAD THE  
LATEST MANUAL!

## User Guide

# Contents

Introduction	2
Tech Specs	2
Overview	3
Operation	4
Before You Begin	4
Mounting the Outdoor Sensor	4
Manual Time Setup	4
Daily Alarm Setup	4
Daily Alarm On/Off	5
Snooze Function	5
12/24 hours mode	5
°C/°F temperature display	5
Max/Min for Indoor/Outdoor Temperature	5
Weather Forecast	5
Illumination	5
Altitude and Weather Icon Selection	5
Low Battery Condition Display	5
RF Wireless Connection to the Outdoor Sensor	6
Warranty	7
2 Year Replacement Guarantee	7

# Introduction

Thank you for purchasing our **WeatherWhiz™ Wireless Weather Reader**. Please read the operating instructions carefully to familiarise yourself with the features and modes of operation before using the instrument.

## Tech Specs



- ✓ Six keys: **MODE / + / - / ALARM / CHANNEL / SNOOZE / LIGHT**
- ✓ Time display: 12/24 format
- ✓ Calendar: Continuous up to 2099, day, date, month
- ✓ Alarm: Dual function with 5 minute snooze
- ✓ Forecasting: Sunny, partly sunny, cloudy, rainy, stormy
- ✓ Barometer: hPa, inHg
- ✓ Temperature: °C, °F, indoor and outdoor with trend
- ✓ Temperature range: Inside: 0~50°C, Outside: -20~60°C
- ✓ Battery indication: Low indication
- ✓ Batteries (not included): Indoor: 3× AA, LR06, 1.5V / Outdoor 2× AAA, LR03, 1.5V
- ✓ Backlight: Blue LED
- ✓ Sensor frequency: 433MHz with 3× channels
- ✓ Transmission range: 50m without interference, at least 1m above ground

**SKU CODE: WS5061**  
Copyright © Holman Industries 2025

**Customer Service**  
support@holmanindustries.com.au  
www.holmanindustries.com.au

**RWC Reliance Worldwide Corporation (Aust.) Pty. Ltd.**  
27-28 Chapman Place  
Eagle Farm, QLD, Australia 4009

# Overview



- |                                  |                                     |
|----------------------------------|-------------------------------------|
| 1. Air pressure trend            | 14. Air pressure reading            |
| 2. Freeze                        | 15. Outdoor channel                 |
| 3. Weather                       | 16. RF symbol                       |
| 4. Trend of indoor temperature   | 17. Max/min for outdoor temperature |
| 5. Max/min of indoor temperature | 18. Trend of outdoor temperature    |
| 6. Indoor                        | 19. Outdoor temperature             |
| 7. Indoor temperature            | 20. Low battery of outdoor sensor   |
| 8. Low battery of indoor station | 21. Week                            |
| 9. Cycle symbol for channel      | 22. Day of week                     |
| 10. Date                         | 23. Alarm 1                         |
| 11. Month                        | 24. Alarm 2                         |
| 12. Time                         |                                     |
| 13. Snooze                       |                                     |

- A. **SNOOZE/LIGHT**
- B. **MODE**
- C. **ALARM**
- D. **+**
- E. **-**
- F. **CHANNEL**
- G. Battery compartment

- i** Insert the batteries in the transmitter before beginning
- i** Obstructions can substantially constrain the coverage of the transmitter
- i** Protect the transmitter from direct sunlight and rain

# Operation

## Before You Begin

---

1. Open the battery compartment located at the rear side of each device
2. Place the batteries in the battery compartment as per the polarity shown
3. **ALTITUDE** will flash. Use **+** / **-** to set the altitude of your position
4. Press **SNOOZE/LIGHT**
5. The weather symbol will flash. Use **+** / **-** to choose the weather
6. Press **SNOOZE/LIGHT**
7. **hPa** and **inHg** will flash. Use **+** / **-** to select
8. The **Indoor Display Console** is now connecting to the **Outdoor Sensor**. This process takes about 3 minutes. The display will then show the outdoor temperature
9. In case of reception failure, press **CHANNEL** for more than 3 seconds to receive again

## Mounting the Outdoor Sensor

---

- i** We suggest the outdoor sensor to be hung as shown
- i** Do not place outside, and try to avoid direct sunshine or rain as much as possible



## Manual Time Setup

---

1. Press and hold **MODE** for 3 sec
  2. **12/24 hr** format will flash; use **+** / **-** to select, press **MODE** to confirm
  3. **HOURL** will flash; use **+** / **-** to select, press **MODE** to confirm
  4. **MINUTES** will flash; use **+** / **-** to select, press **MODE** to confirm
  5. **YEAR** will flash; use **+** / **-** to select, press **MODE** to confirm
  6. **MONTH** will flash; use **+** / **-** to select, press **MODE** to confirm
  7. **DATE** will flash; use **+** / **-** to select, press **MODE** to confirm
- i** The clock automatically changes from setup mode to time display if no keys are pressed for 20 sec

## Daily Alarm Setup

---

1. Press **ALARM** to switch from time display to **A1** display
2. Press and hold **ALARM** for 3 sec, the flashing alarm times will show
3. The **HOURL** display of the alarm time will flash; use **+** / **-** to select, press **ALARM** to confirm
4. The **MINUTE** display of the alarm time will flash; use **+** / **-** to select, press **ALARM** to confirm
5. Press **ALARM** again to switch from **A1** display to **A2** display
6. Repeat the above steps to set the time for **A2**

# Operation

## Daily Alarm On/Off

---

1. When showing **A1** alarm time, use **+** or **-** to activate **A1** with alarm symbol showing
2. Press **+** or **-** again to cancel the alarm
3. When showing **A2** alarm time, use **+** or **-** to activate **A2** with alarm symbol showing
4. Press **+** or **-** again to cancel the alarm

**i** **A1** operates from Monday to Friday

**i** **A2** operates from Saturday to Sunday

**i** The clock automatically changes from setup mode to time display if no keys are pressed for 20 sec

**i** Alarms sound for 2 minutes if no key is pressed to stop it

## Snooze Function

---

1. Press the **SNOOZE/LIGHT** while the alarm sounds to activate the snooze function
2. If the snooze function is activated, **SNOOZE** symbol will flashing
3. The alarm repeat after 5 min
4. The snooze function can be stopped by pressing any key

## 12/24 hours mode

---

**i** Time can be shown in 12hr (AM/PM) or 24hr mode

## °C/°F temperature display

---

**i** Temperature can be shown in °C or °F; press the key **-** to switch between modes

## Max/Min for Indoor/Outdoor Temperature

---

**i** Press **+** to display indoor/outdoor max/min of temperature

## Weather Forecast

---



SUNNY



PARTLY CLOUDY



CLOUDY



RAIN



HEAVY RAIN

**i** As the weather is forecast by the barometer, the display may have discrepancies with the actual weather

**i** Hold **SNOOZE/LIGHT** button for 3 sec; weather icons will flash, use **+** or **-** to select the icons

## Illumination

---

**i** Press **SNOOZE/LIGHT** to illuminate the display for 5 sec

## Altitude and Weather Icon Selection

---

1. Hold **SNOOZE/LIGHT** for 3 sec; altitude will flash which
  2. Press **SNOOZE/LIGHT** the weather icon will flash, use **+** or **-** to select weather icon
  3. Press **SNOOZE/LIGHT**, the **hPa** will flash, use **+** or **-** to switch between **hPa** and **inHg**
- i** If altitude is left unadjusted, the barometer reading is set to comparative air pressure
- i** If altitude is set to 0, the barometer reading will be local air pressure

## Low Battery Condition Display

---

**i** Low battery indicators for both the **Indoor Display Console** and **Outdoor Sensor**, are shown in their respective areas on the **Indoor Display Console**

# Operation

## RF Wireless Connection to the Outdoor Sensor

---

1. Press **CHANNEL** to choose an RF channel to read data from up to 3 **Outdoor Sensors** on one **Indoor Display Console**
  2. Press and hold **CHANNEL** for 3 sec to search for an **Outdoor Sensor**
- i** When placing both the **Indoor Display Console** and **Outdoor Sensor**, remember they are subject to interference
  - i** Install both units as close as possible to each other
  - i** Try to avoid outside interference by not placing them near computers, TVs, aerals etc.
  - i** Concrete walls and floors can interrupt transmissions; try to avoid these as much as possible
  - i** If the connection is successful initially but fails occasionally, try to reduce the distance

# Warranty

## 2 Year Replacement Guarantee

---




In Australia, our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. In addition to the rights and remedies you have under laws relating to your Holman product, we also provide you with a Holman warranty. Holman warrants this product against defects caused by faulty workmanship and materials for 2 years from the date of purchase. During this warranty period Holman will replace any defective product. In the event of a product being replaced during the warranty period, the warranty on the replacement product will expire 2 years from the purchase date of the original product, not 2 years from the date of replacement. To the extent permitted by law and without limiting the consumer guarantee, this Holman Replacement Warranty only covers products that have been put to domestic use, and excludes liability for consequential loss or any other loss or damage caused to property of persons arising from any cause whatsoever. It also excludes defects caused by the product not being used in accordance with instructions, accidental damage, misuse, or being tampered with by unauthorised persons, excludes normal wear and tear and does not cover the cost of claiming under the warranty or transporting the goods to and from the place of purchase.

Should you suspect your product may be defective and need some advice, contact Holman Industries:

1300 716 188  
support@holmanindustries.com.au  
11 Walters Drive, Osborne Park 6017 WA

If you consider that this warranty covers your defective product, present your defective product and your receipt as proof of purchase to the place of purchase, where the retailer will replace the product for you on our behalf.



We really appreciate having you as a customer, and would like to say thank you for choosing us.

We recommend registering your new product on our website. This will ensure we have a copy of your purchase and activate an extended warranty. Keep up to date to with relevant product information and special offers available through our newsletter.

[www.holmanindustries.com.au/product-registration/](http://www.holmanindustries.com.au/product-registration/)



Thanks again for choosing Holman

# HOLMAN

For the #SMARTGARDENER   