





€ E5675 CO1605 INSTRUCTION MANUAL

Glossary



Introduction

CO1605 - Digital Tap TImer

Thank you for purchasing this device, please read the operating instructions carefully to familiarise yourself with the features and modes of operation before using the Digital Tap Timer.

Tap Timer Installation

Make sure the washer is in place, then screw the tap timer to the tap. Turn it clockwise (hand tighten only).

There should be no need to use thread seal tape, as long as the tap seals onto the washer

Battery Installation

- · Hold the tap timer with the battery compartment facing you.
- Remove the battery compartment tray.
- · Connect a 9V battery to the battery connector.
- · Insert the connected battery and push in the battery tray.



changing the battery, make sure the battery compartment stays dry

USE ONLY 9V ALKALINE BATTERIES

1. Setting the Current Time



- 1. Press untill the clock is displayed in the top left corner next to "Time". This means you are in "Time" mode.
- 2. Press and the hour will flash.
- 3. Press or to adjust the hour.
- 4. Press to select the minutes.
- 5. Press or to adjust the minutes.
- 6. Press to select the day (the black box will be
- 7. Press to reach the current day. Press to save the day.

2. Setting the Duration

8. Snap-on Hose Connection




"Duration" is the length of time you want the water to run for.

- 1. Press until the hour glass is displayed on the left next to "Duration". This means you are in "Duration" mode.
- 2. The hour display will be flashing, press to or to adjust the hour.

 3. Press to select the minutes
- 4. Press or to adjust the minutes.


3. Setting the Watering Days



"Days" is where you select what day(s) you want to water on.

- 1. Press until the calendar is displayed on the left next to "Days". This means you are in "Day" mode.
- 2. Press and the black box under "M" will flash.
- 3. Press to select that day, press to deselect
- 4. Press
 to scroll through the days, press
 if to reselect that day. vou ne
- 5. Press to save the schedule.


4. Setting the Start Times



"Starts" is the time of day you want your watering to begin. You can schedule up to 4 start times per day.

- 1. Press untill the alarm clock is displayed in the bottom left corner next to "Starts". This means you are in "Starts" mode.
- 2. Start "1" is the time you want your watering to first begin. Use + or - to adjust the hour.
- 3. Press then to adjust the minutes.
- 4. Press to change to the next start time and repeat steps 2 & 3.
- 5. To turn a start time "OFF" adjust the "hour" until it reads "OFF"

Manual Operation



Manual", allows you to manually turn on your tap timer and set a watering duration. NOTE - this will not effect your automatic schedule.

- 1. Press on to begin manual watering. The preset time is 10 minutes. This will start automatically unless the duration is changed.
- 2. Manually set the duration time using tor 3. Once the watering duration has finished the tap timer will automatically end watering and return to the automatic schedule.

Suspending Operation

How to suspend the automatic scheduling Use this feature when you want to temporarily suspend the automatic schedule.

This feature is generally used when it has been raining or during winter

Suspension: Press of and the sprinkler off icon will appear. The schedule is now suspended.

Cancel suspension: To resume the automatic schedule press **OFF**

Manual operation can still be used during suspension.

Troubleshooting

How to stop watering

To stop manual or automatic watering press off

Low battery warning

The battery indicator has 5 levels. 4 levels of battery and 1 flashing bar when the battery is flat.

The tap timer will not water when the battery is in this mode. We advise to change the battery when it is down to 2 bars to ensure reliable watering.


The schedule will be retained in the tap timer for approximately 2 minutes while changing the battery.

Water not turning on

Ensure that the tap timer is not displaying if it is press off until it disappears.

Irrigation Programming

Press to end manual or automatic watering.



Press to increase time or add a day Press to select a function.

Maintenance

Remove the battery if the tap timer will not be used for a long period of time. The tap timer contains an internal filter which has to be removed and cleaned every few months. For longevity of the tap timer ensure to clean the filter on a regular basis.

Technical Data

HOLMAN - Digital Tap Timer

Product code - CO1605

Maximum Water Pressure - 600 kPa Minumum Water Pressure - 60 kPa

Flow Rate - 19L/min at 200 kPa

Power Source - 9 Volt Alkaline Battery Power Consumption - 20 micro amps in standby mode.

Warranty

Warranty We will honour all statutory guarantees that this product is of acceptable quality. (Including that it is fit for purpose)

HOLMAN INDUSTRIES 11 Walters Drive, Osborne Park, WA 6017

Ph: 1300 716 188 www.holmanindustries.com.au





Press to begin manual watering.