




PRODUCT CODE
CO1605

GLOSSARY

- A. UNIVERSAL TAP ADAPTOR
- B. TAP CONNECTION
- C. UNION NUT
- D. LCD DISPLAY
- E. CONTROL BUTTONS
- F. BATTERY COMPARTMENT
- G. CLEAR SCREW-ON COVER
- H. SNAP-ON HOSE CONNECTION



INSTALLATION

Make sure the washer is in place, then screw the Tap Timer to the tap. Turn it clockwise (hand tighten only)


- ❗ There should be no need to use thread seal tape, as long as the tap seals onto the washer

BATTERY INSTALLATION

1. Hold the tap timer with the battery compartment facing you
 2. Remove the battery compartment tray
 3. Connect a 9V ALKALINE battery to the battery connector
 4. Insert the connected battery and push in the battery tray
- ❗ When changing a battery, the timer will hold the current program if you fit the battery within 2 minutes. When changing the battery, make sure the battery compartment stays dry
 - ❗ Use only 9V ALKALINE batteries



SETTING THE CURRENT TIME




1. Press **ON** until the clock is displayed in the top left corner next to 'TIME'. This means you are in 'TIME' mode
2. Press **➡** and the hour will flash
3. Press **+** or **-** to adjust the hour
4. Press **➡** to select the minutes
5. Press **+** or **-** to adjust the minutes
6. Press **➡** to select the day (the black box will be flashing)
7. Press **+** to reach the current day. Press **➡** to save the day

SETTING THE DURATION



- 'DURATION' is the length of time you want the water to run for
1. Press **ON** until the hour glass is displayed on the left next to 'DURATION'. This means you are in 'DURATION' mode
 2. The hour display will be flashing, press **+** or **-** to adjust the hour
 3. Press **➡** to select the minutes
 4. Press **+** or **-** to adjust the minutes

SETTING THE WATERING DAYS



- 'DAYS' is where you select what day(s) you want to water on
1. Press **ON** until the calendar is displayed on the left next to 'DAYS'. This means you are in 'DAY' mode
 2. Press **➡** and the black box under 'M' will flash
 3. Press **+** to select that day, press **-** to deselect that day
 4. Press **➡** to scroll through the days, press **+** if you need to reselect that day
 5. Press **ON** to save the schedule


SETTING THE START TIMES



- 'STARTS' is the time of day you want your watering to begin. You can schedule up to 4 start times per day
1. Press **ON** until the alarm clock is displayed in the bottom left corner next to 'STARTS'. This means you are in 'STARTS' mode
 2. Start '1' is the time you want your watering to first begin. Use **+** or **-** to adjust the hour
 3. Press **➡** then **+** or **-** to adjust the minutes

4. Press **ON** to change to the next start time and repeat steps 2 and 3
5. To turn a start time 'OFF' adjust the 'HOUR' until it reads 'OFF'

MANUAL OPERATION



- ON** 'MANUAL' allows you to manually turn on your tap timer and set a watering duration.
- ❗ This will not effect your automatic schedule.

MANUAL OPERATION CONT.

1. Press **-** to begin manual watering. The pre-set time is 10 minutes. This will start automatically unless the duration is changed
2. Manually set the duration time using **-** or **+**
3. Once the watering duration has finished the tap timer will automatically end watering and return to the automatic schedule

SUSPENDING OPERATION

Use this feature when you want to temporarily suspend the automatic schedule. This feature is generally used when it has been raining or during winter.

Suspension: Press **w**



MANUAL WATERING

OPTION 1: Manual Watering

To start Manual Watering, turn the 'INTERVAL' dial to 'RESET'. Turn the 'RUN TIME' dial to 'ON'. Turn on your tap and water as needed. To stop watering, turn your tap off. Turn the 'RUN TIME' dial to 'OFF', or re-enter the watering operation

OPTION 2: Manual Watering (Auto-Stop)

To start Manual Watering with an auto-stop, turn the 'INTERVAL' dial to 'RESET'. Turn the 'RUN TIME' dial to 'ON'. Turn on your tap, watering will stop once 'RUN TIME' minutes have lapsed



TECHNICAL DATA

PRODUCT: Low Pressure Tap Timer
 PRODUCT CODE: CO1603
 MAXIMUM WATER PRESSURE: 600 kPa
 BATTERY: Use 2 x AAA ALKALINE batteries
 FLUID: Only use cold water with NO added chemicals
 FREQUENCY OPTIONS: Every 1 hrs, 2 hrs, 3 hrs, 4 hrs, 6 hrs, 8 hrs, 12 hrs, 24 hrs, 48 hrs, 72 hrs, Week, Reset
 RUN TIME OPTIONS: 1, 3, 5, 10, 15, 20, 30, 60, 90, 120, ON, OFF
 WARNINGS: Do not use this device without the appropriate filter
 Every 4 seconds the LED will flash to confirm the battery is working. If the LED flashes any quicker, please replace the batteries

We really appreciate having you as a customer, and would like to say thank you for choosing us. Should you have any questions about this product or its operation please call customer service on 1300 716 188

HOLMAN
 For the #SMARTGARDENER

Head Office/Service
 11 Walters Drive, Osborne Park WA 6017
 Tel: +61 8 9416 9999 Fax: +61 8 9416 9920
 support@holmanindustries.com.au
 www.holmanindustries.com.au

Copyright © 2020 Holman Industries