



PRODUCT CODE
CO1605

BATTERY INSTALLATION


1. Hold the **Tap Timer** with the **BATTERY COMPARTMENT** facing you
2. Remove the **BATTERY COMPARTMENT** tray
3. Connect a 9V alkaline battery to the battery connector
4. Insert the connected battery and push in the **BATTERY COMPARTMENT** tray

i When changing a battery, the **Tap Timer** will hold the current program if you fit the battery within 2 minutes. When changing the battery, make sure the battery compartment stays dry

i Use only 9V alkaline batteries



SETTING THE WATERING DAYS



DAYS is where you select what day(s) you want to water on.

1. Press **ON** until the calendar is displayed on the left next to **DAYS**. This means you are in **DAYS** mode
2. Press **➡** and the black box under **M** will flash
3. Press **+** to select that day, press **-** to deselect that day
4. Press **➡** to scroll through the days, press **+** if you need to reselect that day
5. Press **ON** to save the schedule

SUSPENDING OPERATION CONT.

OFF The schedule is now suspended.

Cancel Suspension: to resume the automatic schedule press **OFF**.


Manual operation can still be used during suspension.

TROUBLESHOOTING

To stop manual or automatic watering press **OFF**.

Low battery warning: The battery indicator has 5 levels. 4 levels of battery and 1 flashing bar when the battery is flat. The **Tap Timer** will not water when the battery is in this mode. We advise to change the battery when it is down to 2 bars to ensure reliable watering.

SETTING THE START TIMES



START is the time of day you want your watering to begin. You can schedule up to 4 start times per day.

1. Press **ON** until the alarm clock is displayed in the bottom left corner next to **START**. This means you are in **START** mode
2. Start **1** is the time you want your watering to first begin. Use **+** or **-** to adjust the hour
3. Press **➡** then **+** or **-** to adjust the minutes

FUNCTIONS

- OFF** Press to end manual or automatic watering
- ➡** Press to scroll through the programming modes
- Press to decrease time or eliminate a day
- +** Press to increase time or add a day
- ➡** Press to select a function
- ON** Press to begin manual watering

MAINTENANCE

Remove the battery if the **Tap Timer** will not be used for a long period of time. The **Tap Timer** contains an internal filter which has to be removed and cleaned every few months.


GLOSSARY

- A. UNIVERSAL TAP ADAPTOR
- B. TAP CONNECTION
- C. UNION NUT
- D. LCD DISPLAY
- E. CONTROL BUTTONS
- F. BATTERY COMPARTMENT
- G. CLEAR SCREW-ON COVER
- H. SNAP-ON HOSE CONNECTION


INSTALLATION

Make sure the washer is in place, then screw the **Digital Tap Timer** to the tap. Turn it clockwise (hand tighten only).

i There should be no need to use thread seal tape, as long as the tap seals onto the washer



SETTING THE CURRENT TIME



1. Press **ON** until the clock is displayed in the top left corner next to **TIME**. This means you are in **TIME** mode
2. Press **➡** and the hour will flash
3. Press **+** or **-** to adjust the hour
4. Press **➡** to select the minutes
5. Press **+** or **-** to adjust the minutes
6. Press **➡** to select the day (the black box will be flashing)
7. Press **+** to reach the current day. Press **➡** to save the day

SETTING THE DURATION



DURATION is the length of time you want the water to run for.

1. Press **ON** until the hour glass is displayed on the left next to **DURATION**. This means you are in **DURATION** mode
2. The hour display will be flashing, press **+** or **-** to adjust the hour
3. Press **➡** to select the minutes
4. Press **+** or **-** to adjust the minutes

MANUAL OPERATION CONT.


1. Press **ON** to begin manual watering. The pre-set time is 10 minutes. This will start automatically unless the duration is changed
2. Manually set the duration time using **+** or **-**
3. Once the watering duration has finished the **Tap Timer** will automatically end watering and return to the automatic schedule

SUSPENDING OPERATION

Use this feature when you want to temporarily suspend the automatic schedule. This feature is generally used when it has been raining or during winter.

Suspension: Press **OFF** and the sprinkler off icon will appear.

MANUAL OPERATION



ON **MANUAL** allows you to manually turn on your tap timer and set a watering duration.

i This will not effect your automatic schedule

TECHNICAL DATA

- Max Water Pressure: 600kPa
- Min Water Pressure: 60kPa
- Flow Rate: 19L/min at 200kPa
- Power Source: 9 volt alkaline battery
- Power Consumption: 20 micro amps in standby mode

We recommend registering your new product to ensure we have a copy of your purchase, and to activate an extended warranty. Keep up to date with relevant product information and special offers available through our newsletter.

www.holmanindustries.com.au/product-registration/

HOLMAN

For the #SMARTGARDENER

Head Office/Service
11 Walters Drive, Osborne Park WA 6017
Tel: +61 8 9416 9999 Fax: +61 8 9416 9920
support@holmanindustries.com.au
www.holmanindustries.com.au

Copyright © 2020 Holman Industries